

Deye Hybrid Inverter

Instructions for installation and setting up the Deye inverter.

- [Deye Hybrid installation diagram](#)

Deye Hybrid installation diagram

Link to video explanation.

<https://www.youtube.com/watch?v=l4f4TGs1CgE>

Zero Export to LOAD. Battery First.

First Scenario when PV Power is MORE.

1. PV Power --> Battery.
2. PV Power --> Backup Load.
3. PV Power --> Feed Grid. (If "Solar Sell" options is checked)

InsOmniA